

In-Ground Flexible Delineator Installation Instructions

Installing Into Loose Soil

- Use a spade or shovel and dig narrow hole
- Place the In-Ground Delineator into the opening approximately 18" deep
- Backfill and tamper the hole and ensure the Delineator is secure

Installing Into Compact Soil

- If a spade or shovel can penetrate soil, use installation method above
- If soil is too hard or frozen, an auger might be necessary
 - o A 4" auger is recommended
 - o Position the auger at the hole location
 - o Auger a hole to proper depth of 18"
 - o Insert Delineator, then backfill and tamper