

INSTRUCTIONS

Crowd Blocker Barriers

COMPONENTS



1 Barrier Panel



2 Connectors



2 Rubber Feet

ASSEMBLY

Step 1. Insert the solid end of the Connector into the hole of the Rubber Foot. Repeat.



Step 2. Using a sturdy block as a lever, turn the Connectors counter-clockwise until the pronged ends are in line with the rubber feet, as shown. NOTE: Turning the rubber feet after they are installed onto the barrier could cause the barrier panel to break.



Step 3. Align the Panel over the two pronged ends of the Connectors. Carefully push down on the Panel until the Connector prongs click into each side of the panel.



Step 4. Connect multiple Barriers with the linking brackets to achieve the desired configuration.

