

Description	Qty.
Bike Rack End Direct Bury	2
5' Bike Fence Direct Bury	1
5' Bottom Rail Direct Bury	2
3/8" X 1-1/2" SS Hex Bolt	8
3/8" SS Nylock Nut	8
3/8" SS Washer	16

- 1 Drill plastic out of the mounting holes on the ends, rails and fence using a 7/16° dia. drill bit.
- 2 Fasten the fence to the rack ends loosely.
- 3 Fasten the rails to the rack ends loosely.
- 4 Check the alignment of the parts and tighten all bolts securely.
- 5 Drill two 12" diameter holes in the ground per the above drawing.
- 6 Position bike rack in holes and level.
- 7 Fill holes with concrete no higher then ground level.

## Periodic check of bolt tightness recommended.

In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.