Instructions

Stripe Marking Machine

Assembly

- 1. Loosen wing nuts on handle and sides of machine.
- 2. Pull handle upright until it locks into place.
- 3. Tighten wing nuts on handle and sides of machine.

Can Loading & Operation

- 1. Shake aerosol can vigorously for one minute and occasionally during use.
- 2. Turn can upside-down and place in can holder. The long sides of the sprayhead must be parallel to the axle. Then slide paint can towards center of cart where it will snap into place.
- 3. Push machine and squeeze trigger to activate paint spray. To avoid any possible paint build-up when starting, make sure machine is in motion when passing over the starting point.
- 4. To remove spray can, slide toward side of machine and lift out.

Adjusting Line Width

- 1. Creates stripes approximately 2 to 4 inches wide.
- 2. Adjust line width by loosening wing screws and raising or lowering can holder (raise to make line wider or lower to make line narrower).
- 3. After the can holder is at the desired height, retighten the wing screws.



