







3 SIDED KIOSK INSTRUCTIONS

MC3220 REV #2
2/26/2019



3 SIDED KIOSK INSTRUCTIONS




OTHER REQUIRED MATERIALS FOR INGROUND MOUNTING (NOT INCLUDED)

- 2 - 80lb BAG OF SAKCRETE
- 1 - POST HOLE DIGGER
- GUIDE WIRES
- A FRIEND TO HELP


**COMPONENTS &
TOOLS REQUIRED
FOR ASSEMBLY**

1/10


3 SIDED KIOSK INSTRUCTIONS




12
1/4" x 1-1/2" Lag Screws
HLAG025C150188



24
1/4" x 3-1/2" Lag Screws
HLAG025C350188



36
1/4" Flat Washers
WUSS025WAS188



9
#8 x 1-5/8" Flat Head Screws
DSSF010C400188

REQUIRED TOOLS (NOT INCLUDED)


- 1 - 7/16" SOCKET
- 1 - SCREW GUN
- 1 - LEVEL
- 1 - #2 SQUARE DRIVE

**COMPONENTS &
TOOLS REQUIRED
FOR ASSEMBLY**


2/10

3 SIDED KIOSK INSTRUCTIONS

Pockets always face down
1-1/2" Lag Screw always in inside corner




3 SIDED KIOSK INSTRUCTIONS




3 SIDED KIOSK INSTRUCTIONS

Attach second frame supports



Attach second post




STEP 2
ATTACH SECOND
FRAME SUPPORTS


5/10

3 SIDED KIOSK INSTRUCTIONS


Attach third frame supports



Attach third post





3 SIDED KIOSK INSTRUCTIONS



Attach Roof


- Raise the top of the frame assembly at least 10 inches off the ground to attach the roof
- Secure roof using the #8 x 1-5/8" flat head screws (I) provided




3 SIDED KIOSK INSTRUCTIONS

Inground Mount


- Stand the frame assembly upright and place in desired area
- On the ground, mark the location of the posts
- Dig three 12" diameter holes to a depth of 2 to 3 feet (Some areas require deeper holes due to frost, see map on next page)
- Place assembly into the holes, level and fill with concrete
- You may need to use guide wires to hold the assembly level while the concrete sets



Post in Poured
Concrete Footing




3 SIDED KIOSK INSTRUCTIONS



3 SIDED KIOSK INSTRUCTIONS

Attach Message Centers

- Set a message center (B) into the frame assembly
- Insert four 1/4" x 3-1/2" lag screws (G) and 1/4" flat washer (H) through the guide holes in the top and bottom of the message center (B)
- Tighten and repeat for the other two message centers




STEP 6
ATTACH MESSAGE
CENTERS


10/10

THREE-SIDED KIOSK INGROUND MOUNT

MC3220 REV #2
2/26/2019




FRONT



TOP

THREE-SIDED KIOSK INGROUND MOUNT

MC3220 REV #2
2/26/2019



HARDWARE: STAINLESS STEEL
MATERIAL: RECYCLED PLASTIC, ACRYLIC, 1/4" CORK

