


4' Square Picnic Table With Back Rests Expanded Metal





ITEM NO.	DESCRIPTION	QTY.
1	Square Table Top	1
2	Sq./Rnd Table Free Standing Leg W/Back	8
3	Sq./Rnd Table Leg Support Bracket	1
4	40" Seat	8
5	3/8"x1-1/2" SS Hex Bolt	48
6	3/8" SS Flat Washer	96
7	3/8" SS Nylock Nut	48



- Place the tabletop upside down on top of a pair of sawhorses or 12" blocks (cover the blocks with cardboard) and drill out the 8 holes in the frame using a 7/16" drill bit. Drill out the 8 holes in the leg bracket with the same 7/16" drill bit.
- 2. 3.
- Drill out the 6 holes on each of the table legs using the 7/16" drill bit.
- 4. Attach the leg top to the inside of the tabletop frame with a hex bolt, 2 washers and a nylock nut. Do not tighten completely.
- 5. Repeat step 4 by attaching another leg on the same side as the first.
- Attach the leg bracket to the threaded stud on the 2 legs that you just attached to the tabletop. Use a 6. washer and nylock nut. Again do not tighten completely.
- 7. Continue attaching the legs to the tabletop and leg bracket. When you have all of the legs attached, flip the table right side up.
- 8. Drill out the 4 holes in the seat/back and install them onto the legs. Note: The cross frames on the seat/back aren't the same distance from the ends. Be sure to align the seat with the back. The cross frame on the seat/back attaches to the same side of the mounting plate on each leg. (Both on the left or both on the right)
- 9. When you have all of the parts attached you can begin tightening the bolts. Make sure the table is on a level surface and adjust the legs and set/backs so that they are level as you tighten each component.

In Accordance to California law: WARNING This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

Periodic check of bolt tightness recommended.