



Installation Guide

Components:


- Standard Recycled Rubber Speed Bump
- Lag Bolts or Rebar Spikes

What you will need:

- PPE (gloves, safety glasses, pylons/ signage to secure work site)
- Mallet
- Heavy duty electric drill
- 1/2" masonry bit
- A drive socket and a power tool for installation of the lag bolts
- *if using lag bolts, a masonry bit for the metal shields

Installation Instructions using Lag Bolts

(recommended for installation into concrete surfaces):

Step 1:	Use 1/2" lag bolts (4-6" long). Drill 1/2" diameter pilot holes (3-4" in depth) through the product's installation holes. 
Step 2:	Remove the speed bump; re-drill the holes for the diameter and depth required by the metal shields.
Step 3:	Install the metal shields, re-position the speed bump and fasten with lag bolts.

Installation Instructions using Rebar Spikes

(recommended for installation into asphalt surfaces):

Step 1:	Drill 1/2" diameter holes (3-4" in depth) in the asphalt in the desired location through the speed bump holes on the top of the product.
Step 2:	Drive 1/2" rebar spike through the holes in the speed bump 